



MULTI-DECK MERCHANDISER INSTALLATION & OPERATIONS MANUAL

PF-SC (R-290)

WARNING / FOR YOUR SAFETY

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WARNING

R290 flammable refrigerant in use. Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.

Table of Contents

Technical Reference	1-5	Airflow & Defrost	16
General Information	6	Case Cleaning	17-19
Case Installation	7-10	Troubleshooting	20
Case Connections	11-12	Safety Devices & Service	21-25
Lighting & Power Supplies	13-14	Parts Ordering	26
Pre-Power Checklist	15	Appendices	

To ensure proper functionality and optimum performance, it is STRONGLY recommended that Hillphoenix specialty cases be installed/serviced by qualified technicians who have experience working with commercial refrigerated display merchandisers and storage cabinets. For a list of Hillphoenix-authorized installation/service contractors, please visit our website at www.hillphoenix.com.



Hillphoenix®

a **DOVER** company

Important

At Hillphoenix[®], the safety of our customers and employees, as well as the ongoing performance of our products, are top priorities. To that end, we include important warning messages in all Hillphoenix installation and operations handbooks, accompanied by an alert symbol paired with the word "DANGER", "WARNING", or "CAUTION".

All warning messages will inform you of the potential hazard; how to reduce the risk of case damage, personal injury or death; and what may happen if the instructions are not properly followed.

This manual must be stored near the display case where it can be easily consulted. If this manual does not provide the information you require please contact Hillphoenix for more information.



DANGER

Indicates an immediate threat of death or serious injury if all instructions are not followed carefully.



WARNING

Indicates a potential threat of death or serious injury if all instructions are not followed carefully.



CAUTION

Indicates that failure to properly follow instructions may result in case damage.

Revision History

- new manual format_08/21
- technical reference_01/23
- technical reference and compliance_02/25
- technical reference and appendices_03/26
- added compliance information_05/26


PF-SC

Self-Service Open Multi-Deck Merchandiser
3', 4' & 6' (Bakery/Beverage/Cheese/Deli)



GENERAL NOTES:

- "----" Indicates that the feature is not an option on this case model and/or the data is not yet available at this time.
- 6' Case length is only available for the 54" tall case model.
- WARNING: R-290 flammable refrigerant in use. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.



SHIPPING WEIGHT	
Case	Weight
PF-SC	----



ENGINEERED FOR STORES WITH NSF TYPE II AMBIENT CONDITIONS, NOT TO EXCEED 80°F (27°C) AND 55% RELATIVE HUMIDITY. DUE TO ENGINEERING IMPROVEMENTS SPECIFICATIONS MAY CHANGE WITHOUT NOTICE. ALL MEASUREMENTS ARE TAKEN PER ASHRAE-72 SPECIFICATIONS. HILLPHOENIX REFRIGERATED DISPLAY CASES FOR SALE IN THE UNITED STATES MEET OR EXCEED DEPARTMENT OF ENERGY 2017 REQUIREMENTS. NUMBERS ARE BASED ON STANDARD CASE SIZES. CONSULT ENGINEERING.

PF-SC

Rev. Date	Rev. #	Rev. Title
05-19-26	4	DATA UPDATE
03-23-26	3	ENDVIEW UPDATE



PF-SC

Self-Service Open Muti-Deck Merchandiser
3', 4' & 6' (Bakery/Beverage/Cheese/Deli)



SYSTEM REQUIREMENTS

Case Height	Case Length	Volts	Phase	Total Amps	Minimum Circuit Ampacity (MCA)	Maximum Overcurrent Protection (MOP)	THR (BTUH)
48"	3'	120	1	6.56	7.89	15.00	790
48"	4'	120	1	10.13	12.23	15.00	1220
48"	3'	120/208	1	5.30	6.63	15.00	1100
48"	4'	120/208	1	8.40	10.50	15.00	1750
54"	3'	120	1	8.17	9.92	15.00	980
54"	4'	120	1	7.42	9.10	15.00	900
54"	6'	120	1	14.61	15.90	22.00	1750
54"	3'	120/208	1	6.10	7.63	15.00	1269
54"	4'	120/208	1	6.10	7.60	15.00	1269
54"	6'	120/208	1	7.54	8.90	15.00	1568
72"	3'	120	1	9.92	11.90	15.00	1190
72"	4'	120	1	16.01	19.39	20.00	1921
72"	3'	120/208	1	6.10	7.63	15.00	1269
72"	4'	120/208	1	11.70	14.63	20.00	2434

ELECTRICAL DATA

Case Length	Fans Per Case	High Efficiency Fans		Anti-Condensate Fans		Drain Heaters	
		120 Volts		120 Volts		120 Volts	
		Amps	Watts	Amps	Watts	Amps	Watts
3'	1	0.30	25.00	---	---	---	---
4'	2	0.60	25.00	---	---	---	---
6'	2	0.60	25.00	---	---	---	---

LIGHTING DATA

Case Length	Lights Per Row	Light Length	Clearvoyant 4 LED Lighting (Per Light Row)			
			Standard Power (Cornice or Shelf)		High Power (Cornice)	
			120 Volts		120 Volts	
			Amps	Watts	Amps	Watts
3'	1	3'	0.03	4.7	0.08	11.9
4'	1	4'	0.04	5.9	0.11	14.9
6'	2	3'	0.03	4.7	0.08	11.9

NOTES:

- "----" Indicates that the feature is not an option on this case model and/or the data is not yet available at this time.
- Listed discharge air velocity represents the average velocity at the peak of defrost.
- LRA - Locked Rotor Amps
- RLA - Running Load Amps
- 6' Case length is only available for the 54" tall case model.



ENGINEERED FOR STORES WITH NSF TYPE II AMBIENT CONDITIONS, NOT TO EXCEED 80°F (27°C) AND 55% RELATIVE HUMIDITY. DUE TO ENGINEERING IMPROVEMENTS SPECIFICATIONS MAY CHANGE WITHOUT NOTICE. ALL MEASUREMENTS ARE TAKEN PER ASHRAE-72 SPECIFICATIONS. HILLPHOENIX REFRIGERATED DISPLAY CASES FOR SALE IN THE UNITED STATES MEET OR EXCEED DEPARTMENT OF ENERGY 2017 REQUIREMENTS. NUMBERS ARE BASED ON STANDARD CASE SIZES. CONSULT ENGINEERING.

PF-SC

Rev. Date	Rev. #	Rev. Title
05-19-26	4	DATA UPDATE
03-23-26	3	ENDVIEW UPDATE



PF-SC

Self-Service Open Muti-Deck Merchandiser
3', 4' & 6' (Bakery/Beverage/Cheese/Deli)


GUIDELINES AND CONTROL SETTINGS

Case Height	Case Length	24hr Energy Usage (kWh)	Discharge Air (°F)	Discharge Air Velocity (FPM)
48"	3'	---	---	---
48"	4'	---	28 - 30	200
54"	3'	---	---	---
54"	4'	14.63	28 - 30	143
54"	6'	21.50	28 - 30	168
72"	3'	---	---	---
72"	4'	22.49	28 - 30	200

CONDENSING UNIT DATA

Case Height	Case Length	Volts	Phase	HP	RLA (Amps)	LRA (Amps)	Qty	Refrig.	Grams	Condenser Fans	
										Amps	Watts
48"	3'	115	1	---	5.30	32.0	1	R-290	135	0.70	30
48"	4'	115	1	---	8.40	40.2	1	R-290	175	0.70	30
54"	3'	115	1	---	6.10	42.0	1	R-290	135	0.70	30
54"	4'	115	1	---	6.10	42.0	1	R-290	132	0.70	30
54"	6'	115	1	---	6.10	42.0	2	R-290	132	1.40	60
72"	3'	115	1	---	6.10	42.0	1	R-290	149	0.70	30
72"	4'	115	1	---	11.70	60.0	1	R-290	200	0.70	30

MINIMUM ROOM SIZE

Case Height	Case Length	Case Charge (grams)	Case Charge (lbs)	Minimum Room Size	
				SQM	SQFT
48"	3'	135	0.30	6.5	69.5
48"	4'	175	0.39	8.4	90.1
54"	3'	124	0.27	5.9	63.9
54"	4'	132	0.29	6.3	68.0
54"	6'	124	0.27	5.9	63.9
72"	3'	149	0.33	7.1	76.7
72"	4'	200	0.44	9.6	103.0

DEFROST CONTROLS

Case Length	Defrosts Per Day	Electric Defrost		Timed-Off Defrost		Hot Gas Defrost	
		Fail-Safe (Min)	Termination Temp (°F)	Fail-Safe (Min)	Termination Temp (°F)	Fail-Safe (Min)	Termination Temp (°F)
3'	4	---	---	30	45	---	---
4'	4	---	---	30	45	---	---
6'	4	---	---	30	45	---	---



ENGINEERED FOR STORES WITH NSF TYPE II AMBIENT CONDITIONS, NOT TO EXCEED 80°F (27°C) AND 55% RELATIVE HUMIDITY. DUE TO ENGINEERING IMPROVEMENTS SPECIFICATIONS MAY CHANGE WITHOUT NOTICE. ALL MEASUREMENTS ARE TAKEN PER ASHRAE-72 SPECIFICATIONS. HILLPHOENIX REFRIGERATED DISPLAY CASES FOR SALE IN THE UNITED STATES MEET OR EXCEED DEPARTMENT OF ENERGY 2017 REQUIREMENTS. NUMBERS ARE BASED ON STANDARD CASE SIZES. CONSULT ENGINEERING.




PF-SC

Rev. Date	Rev. #	Rev. Title
05-19-26	4	DATA UPDATE
03-23-26	3	ENDVIEW UPDATE



PF-SC

Self-Service Open Multi-Deck Merchandiser
3', 4' & 6' (Bakery/Beverage/Cheese/Deli)



ENGINEERED FOR STORES WITH NSF TYPE II AMBIENT CONDITIONS, NOT TO EXCEED 80°F (27°C) AND 55% RELATIVE HUMIDITY. DUE TO ENGINEERING IMPROVEMENTS SPECIFICATIONS MAY CHANGE WITHOUT NOTICE. ALL MEASUREMENTS ARE TAKEN PER ASHRAE-72 SPECIFICATIONS. HILLPHOENIX REFRIGERATED DISPLAY CASES FOR SALE IN THE UNITED STATES MEET OR EXCEED DEPARTMENT OF ENERGY 2017 REQUIREMENTS. NUMBERS ARE BASED ON STANDARD CASE SIZES. CONSULT ENGINEERING.


PF-SC

Rev. Date	Rev. #	Rev. Title
05-19-26	4	DATA UPDATE
03-23-26	3	ENDVIEW UPDATE



PF-SC

Self-Service Open Multi-Deck Merchandiser
3', 4' & 6' (Bakery/Beverage/Cheese/Deli)



ENGINEERED FOR STORES WITH NSF TYPE II AMBIENT CONDITIONS, NOT TO EXCEED 80°F (27°C) AND 55% RELATIVE HUMIDITY. DUE TO ENGINEERING IMPROVEMENTS SPECIFICATIONS MAY CHANGE WITHOUT NOTICE. ALL MEASUREMENTS ARE TAKEN PER ASHRAE-72 SPECIFICATIONS. HILLPHOENIX REFRIGERATED DISPLAY CASES FOR SALE IN THE UNITED STATES MEET OR EXCEED DEPARTMENT OF ENERGY 2017 REQUIREMENTS. NUMBERS ARE BASED ON STANDARD CASE SIZES. CONSULT ENGINEERING.

PF-SC

Rev. Date	Rev. #	Rev. Title
05-19-26	4	DATA UPDATE
03-23-26	3	ENDVIEW UPDATE



GENERAL INFORMATION

Thank you for choosing Hillphoenix for your food merchandising needs. This manual contains important technical information and will assist you with the installation and operation of your new Hillphoenix specialty cases. By closely following the instructions, you can expect peak performance; attractive fit and finish; and long case life.

We are always interested in your suggestions for improvements (e.g. case design, technical documents, etc.). Please feel free to contact our Marketing Services group at the number listed below. Thank you for choosing Hillphoenix, and we wish you the very best in outstanding food merchandising.

CASE DESCRIPTION

This manual specifically covers the PF-SC (R-290) bakery, beverage, cheese and deli application self-service open multi-deck merchandiser.

STORE CONDITIONS

Hillphoenix cases are designed to operate in an air-conditioned store that maintains a 75°F (24°C) store temperature and 55% (max) relative humidity (ASHRAE conditions). Case operation will be adversely affected by exposure to excessively high ambient temperatures and/or humidity.

REFRIGERATION SYSTEM OPERATION

Air-cooled condensing units require adequate ventilation for efficient performance.

THIS UNIT CONTAINS R-290 FLAMMABLE REFRIGERANT. USE CAUTION WHEN HANDLING, MOVING OR SERVICING THE DISPLAY CASE. AVOID DAMAGING THE REFRIGERANT TUBING WHICH COULD INCREASE THE RISK OF A LEAK.

SHIPPING CASES

Transportation companies assume all liability from the time a shipment is received by them until the time it is delivered to the consumer. Our liability ceases at the time of shipment.

RECEIVING CASES

Examine fixtures carefully and in the event of shipping damage and/or shortages, please contact the Service Parts Department at the number listed below.

CASE DAMAGE

Claims for obvious damage must be 1) noted on either the freight bill or the express receipt and 2) signed by the carrier's agent; otherwise, the carrier may refuse the claim. If damage becomes apparent after the equipment is unpacked, retain all packing materials and submit a written request to the carrier for inspection within 14 days of receipt of the equipment.

Hillphoenix Specialty Products
703 Franklin Street, PO Box 478
Keosauqua, IA 52565
Website: www.hillphoenix.com

Failure to follow this procedure will result in refusal by the carrier to honor any claims with a consequent loss to the consumer.

If a UPS shipment has been damaged, retain the damaged material, the carton and notify us at once. We will file a claim.

LOST/MISSING ITEMS

Equipment has been carefully inspected to insure the highest level of quality. Any claim for lost/missing items must be made to Hillphoenix within 48 hours of receipt of the equipment. When making a claim please use the number listed below.

SERVICE PARTS & TECHNICAL SUPPORT

For service parts questions regarding our cases, please contact our Service Parts Department at 1-844-HPX-PART (1-844-479-7278) or SpecialtyParts@dooverfoodretail.com

For technical questions regarding our cases, please contact our Technical Support Department at 1-833-280-5714.

CONTACTING THE FACTORY

If you need to contact Hillphoenix regarding a specific fixture, be certain that you have both the case model number and serial number. (This information can be found on the data tag, located at the top-left interior, rear exterior panel or interior rear lower storage of the case. *Location may vary based on case design.*)



CAUTION

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.



WARNING

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.



WARNING

Do not use electrical appliances inside the food/ice storage compartments unless they are of the type recommended by the manufacturer.

LOCATION

This refrigerated display case has been designed for displaying and storing perishable food product. It is engineered for air-conditioned stores with a maximum ambient of 75° F and 55% relative humidity.

When selecting the location for placement of this case, avoid the following conditions:

Excessive Air Movement

1. Doors
2. Air-conditioned vents
3. Other air sources

Excessive Heat

1. Windows
2. Sun
3. Flood lamps 8 feet or less from the product
4. Other heat sources

Note: The following checks shall be applied to installations using flammable refrigerants.

- a. The actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed;
- b. The ventilation machinery and outlets are operating adequately and are not obstructed;
- c. If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
- d. Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- e. Refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

FLOOR PREP

1. Ask the general contractor if your current copy of the building dimensions are the most recently issued. Also, ask for the points of reference from which you should take dimensions to locate the cases.
2. Using chalk lines or a laser transit, mark the floor where the cases are to be located for the entire lineup. The lines should coincide with the outside edges of the case feet.
3. Move case as close as possible to its permanent location. Remove all crating and shipping braces above the shipping pallet. Loosen the plastic dust cover from the pallet, but leave cover over the case to protect it while removing the case from the pallet.
4. The power cord shipping brace (Fig. 1) can be removed with a screw gun. As for case shipping braces, the same would be applied with sled runner or caster construction. If the braces are metal brackets or locks they can be removed with a screw gun. If they are wood blocks they can be removed with a J-bar. **Note: Shipping braces are normally located at each corner of the case. Some case models with casters will use bracing that surrounds the casters entirely and some will use braces that affix to the toekicks at each corner. (Shipping braces used vary and are based on case design for best transport.)**
5. Carefully, if horizontal supports, lift case up and off the pallet. Remove dust cover. Installation hardware ships in a marked packet located inside the case. Remove dust cover. Installation hardware ships in a marked packet located inside the case. (Hillphoenix self-contained display cases are sometimes designed with casters. In most situations, one or two persons can easily move the case into position.) If there are casters simply roll them on to

CASE INSTALLATION

- the store floor to the proper staging area. First remove all crating then all sled runner, caster, and/or power cord shipping braces. (Dependent on case design.)




Fig. 1 Power cord shipping brace

- Leveling is necessary to ensure proper operation of the refrigeration system and drainage of the condensate. Locate the highest point on the positioning lines as a reference for determining the proper height of the shim-pack levelers. A laser transit is recommended for precision and requires just one person. Level adjustable feet by twisting, if applicable, or shim as necessary under vertical stationary or caster supports as this will help ensure that the case is not settling over time.

CAUTION

Failure to properly level the case could result in lack of proper condensation drainage leading to failure of the unit.

- Locate horizontal or vertical (caster) support positions along the chalk line (Fig. 2). Spot properly leveled shim packs at each support location.




Fig. 2 Horizontal (sled runner) or vertical (caster) supports

- (SLED RUNNERS) If necessary, drill a hole in each end of every horizontal support (Fig. 3) and fasten to the floor with concrete anchors. **Note: The holes do not need to be in the exact locations specified here. Be sure that the anchors are close to the end of the horizontal supports and at each corner of the case.**




Fig. 3 Seismic anchoring locations (sled runners)

the store floor to the proper staging area. First remove all crating then all sled runner, caster, and/or power cord shipping braces. (Dependent on case design.)

6. Leveling is necessary to ensure proper operation of the refrigeration system and drainage of the condensate. Locate the highest point on the positioning lines as a reference for determining the proper height of the shim-pack




Fig. 4 Seismic anchoring locations (caster brackets)

CAUTION

Locate the horizontal or vertical (caster) supports under unit before removing from pallet. Failure to do so will damage the finished metal if correct lift points are not identified prior to removal.

CAUTION

These cases are not designed for excessive external weight. Do not walk on top or inside of cases. Doing so may result in case damage and/or personal injury.

LINE-UP & INSTALLATION

NOTE: Install in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.

Single Case

1. Move the case into position. Using a “J” bar, raise the end of the case (under cross support), and lower the horizontal

WARNING

Be certain that your hands and feet are out of the way before lowering the case. Failure to do so may result in serious injury.

support on to the shim packs. Repeat on the other end of the case.

2. Once the case is properly placed on the shim packs, check the vertical plumb of the case by placing a bubble level on the rear wall. Add/remove shim packs as needed. For the horizontal level, repeat this process after placing the bubble level on the front sill.
3. Install the bumper, if applicable, into pre-attached bumper track and snap into place. (Most self-contained cases ship with bumper pre-installed.)
4. After sufficient time has passed to allow for bumper shrinkage, cut away the excess bumper for final fit and finish. Be certain to use an appropriate cutting tool (tubing- or PVC-cutter) to ensure a smooth cut.
5. Install case shelves and reconnect lights. Be aware that differing shelf configurations will affect energy consumption and case performance. Max shelf loading: 200 lbs.
6. Install toekick/compressor compartment access panel back onto the base of case, if applicable.
7. Equipment is designed to be sealed to the floor once installed in final location. This is intended to prevent liquid, dirt, debris, etc. from collecting under the case after installation. **Exception: Cases using casters are not required to be sealed to the floor.**

Once case is set in the final location and all panels are attached, run a bead of silicone/sealant around the bottom edge of the case and the floor to create a barrier to prevent liquid, dirt, debris, etc. from collecting underneath the case.

CAUTION

Do not obstruct ventilation around the base of the display case condensing unit. Obstructing could cause the case to not operate correctly and failure to maintain product temperatures.

Multi-Case

NOTE: Install in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.

1. Remove any shelves (discard the shelf clips) and/or loose items from the cases that may interfere with case joining. Keep all loose items as they will be used later in the installation process.
2. Follow the single-case installation instructions for the first case, excluding #6, then position the next case in the line-up approximately 3' away.

CASE INSTALLATION




Fig. 5 Bolt locations




Fig. 6 Sealing the pipe chase

3. Apply a bead of butyl or silicone sealant to the end of the first case. From the opposite end, push the second case to a position that is approximately 6" from the first case, then position the case on the shim packs.
4. Push the cases tightly together, then lightly bolt them together through the holes provided (Fig. 5). Tighten all the joining bolts until all margins are equal. Be careful not to over tighten.
5. If applicable, the stub-up location can be found under the tank on the customer left. See *technical reference on page 5 for access locations*.
6. Apply case-to-case watershed (supplied) over the end frame seam (Fig. 6). The watershed prevents water from settling in the case joint.
7. Repeat steps 3-6 of this sequence for all remaining cases. Be certain to properly level all cases.
8. Properly align the front panels as needed, then install, if applicable, front panel trim (supplied).
9. Install the bumper into pre-attached bumper track and snap into place.
10. After sufficient time has passed to allow for bumper shrinkage, cut away the excess bumper for final fit and finish. Be certain to use an appropriate cutting tool (tubing-

or PVC-cutter) to ensure a smooth cut.

11. Install case shelves and reconnect lights. Be aware that differing shelf configurations will affect energy consumption and case performance. Max shelf loading: 200 lbs.
12. Install toekick/compressor compartment access panel back onto the base of case, if applicable.
13. Equipment is designed to be sealed to the floor once installed in final location. This is intended to prevent liquid, dirt, debris, etc. from collecting under the case after installation. **Exception: Cases using casters are not required to be sealed to the floor.**

Once case is set in the final location and all panels are attached, run a bead of silicone/sealant around the bottom edge of the case and the floor to create a barrier to prevent liquid, dirt, debris, etc. from collecting underneath the case.

CAUTION

Installation of 3rd-party materials may result in diminished case performance.

CAUTION

Display case shall not be installed in public corridors or lobbies.

CAUTION

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

ELECTRICAL

Electrical hookups are made through the junction box which can be accessed by removing the lower panel to the compressor compartment.

When connecting to the power supply on the case, field wiring should exit box from the side furthest away from case wiring to allow more room inside for wiring connections. The case must be grounded. *For more detailed electrical wiring information (see Appendix A1).*

Prior to plugging in and starting up the case always check the data tag located on the left end exterior panel or top interior of the case, as well as the voltage label found on the main power cord (Fig. 7) which can be found at the rear base panel. **Note:** **Check that the voltage of the receptacle you are going to use for power and the voltage required for the case match.**




Fig. 7 Main power cord voltage label

⚠ CAUTION

Prior to plugging in and starting up the case. Be certain that the voltage of the receptacle you are going to use and the voltage required for the case match. Failure to do so may result in case/system damage.

⚠ CAUTION

Be certain that all electrical connections are compliant with local codes.

⚠ DANGER

CAUTION, RISK OF ELECTRIC SHOCK. If the cord or plug becomes damaged, replace only with a cord and plug of the same type.

⚠ CAUTION

This case must be powered only in electrical installations with ground fault circuit interrupter (GFCI) circuit breakers or residual current device (RCD).

REFRIGERATION & COMPRESSOR COMPARTMENT

A bottom mounted compressor compartment can be accessed by removing the front or rear panel (Fig. 8). See *Appendices for full instructions on how to program the Carel electronic controller.*

Access locations and/or R-290 compartment configurations will vary based on case design. See *technical reference on page 5 for access locations and page 11 for a compressor compartment diagram.*




Fig. 8 Compressor compartment

⚠ CAUTION

Be sure to remove all styrofoam shipping blocks from piping and refrigerant lines. Failure to do so may result in case damage.

⚠ DANGER

When carrying out maintenance tasks inside the refrigerated case or compressor compartment, it is essential to disconnect the power source to the case from the main power.

Pressure Switch & Power Supply

1. After the main power cord (Fig. 7) located at the base panel of the case is plugged in and the power switch (Fig. 9) flipped to ON the case should begin normal operations.
2. After establishing power the light control switch (Fig. 10) (if applicable) located in the upper front interior cornice can be flipped to the ON position. The case should now be fully operational and all lights functioning when in the ON position (if applicable).

⚠ DANGER

ALWAYS CHECK THE THERMOSTAT CURRENT RATING. It may have a limited current, as low as 2A. If necessary protect digital thermostat contacts with a contractor.

CASE CONNECTIONS




Fig. 9 Lower panel power switch



Fig. 10 Upper cornice light switch

R-290 COMPRESSOR COMPARTMENT DIAGRAM


Single Fan



A	Fan Guard	E	Compressor	I	Condenser Bracket
B	Condenser Fan	F	Dissipater Pan	J	Filter Dryer
C	High Pressure Switch	G	Compressor Bracket	K	Condenser Coil
D	Low Presser Switch	H	High Side Access		

Note: Access locations and/or compartment configurations will vary based on case design.

Dual Fan



- A Fan Guard
- B Condenser Fan
- C High Pressure Switch
- D Low Pressure Switch
- E Compressor
- F Dissipation Pan
- G Compressor Bracket
- H High Side Access
- I Condenser Bracket
- J Filter Dryer
- K Condenser Coil

Note: Access locations and/or compartment configurations will vary based on case design.

GENERAL LIGHTING INFORMATION

Hillphoenix cases are equipped with LED luminaires and feature specially designed light reflectors in the cornice to improve the illumination of products. LED power supplies operate both the cornice and shelf lights and are located above the cornice reflectors.

The lighting system has an ON/OFF switch located in the raceway, power box or at the inside back of the case. Once a case has been properly positioned in the store the lights may be turned on to verify that they are connected and functioning properly.

To ensure peak performance, it is advisable to run the lighting systems only when the store climate control is on and case refrigeration is started. **Note: It is highly recommended that the ambient store temperature not exceed 80 °F.**

DANGER

SHOCK HAZARD

Always disconnect power to case when cleaning, servicing or configuring components of the lighting system. Failure to do so may result in serious injury or death.

WARNING

Using improper DC power supplies may damage the luminaires, resulting in sub-standard operation and increased chances of safety issues/injury.

WARNING

Never replace a 24V DC power supply with a T8 or T5 ballast of any kind! Ballasts use alternating current (AC) instead of direct current (DC) and operate at a much higher voltage than is used by this LED system. Doing so will damage the LED system and increases the chance of safety issues/injury.

LED DRIVER/POWER SUPPLY ACCESS

To gain access to the LED driver or power supplies remove the raceway cover (Fig. 11). The power supply can be located at the customer left side of the case.

REPLACING LED LIGHTS

Once store power is connected the Clearvoyant LED system should operate without the need for any significant maintenance.

nance for several years. Should a power supply need to be removed and/or replaced, turn off the power to the case before proceeding. Be certain to replace the power supply with genuine Hillphoenix parts or a comparable UL-listed Class-2 rated regulated 24V DC power supply with 100W output capacity.




Fig. 11 Clear view of the driver

LED LUMINAIRES

Removing LED luminaires:

1. Unplug the luminaire (Fig. 12).




Fig. 12 LED light power cord

2. Remove the screws from the light clamps (Fig. 13) while keeping hold of the light. Once the screws are removed the light rod will come away from the case with the clamps still holding to the light.
3. Remove the closed clamps and inner rings (Fig. 14) by unclipping the clamp ends located above the screw opening. This will release the grip around the inner ring (Fig. 15) and allow for the two pieces to be separated from one another.
4. Carefully remove the inner rings from around the light rod.



CAUTION

Too much tension on the inner clamp rings while removing them from an LED light rod may cause breakage. Use only enough tension for removal.




Fig. 13 LED light & ring/clamp




Fig. 14 Closed clamp

Fig. 15 Open clamp

Re-installing LED luminaires:

1. Place a ring (Fig. 16) around each end of the light rod and rotate until both edges of the rod line-up and snap ahold to the ridges in the ring.
2. Slide a clamp (Fig. 16) over each ring and close them tight around the rings by clipping together the clamp ends located above the screw opening.
3. Line-up the closed clamps (Fig. 14) and light rod with the existing screw holes on the case and re-attach.
4. Rotate the light rod into desired position after the clamps are firmly re-attached.



Fig. 16 LED ring and clamp

Before powering-up the case, be certain that all of the steps listed below have been completed to ensure proper case functionality, safety and compliance with warranty terms.

- ☐ **Have you thoroughly examined the case for shipping damage? (see pg. 6)**
- ☐ **Have you checked to ensure the case is horizontally level? (see pg. 7)**
- ☐ **Have you checked all exposed refrigeration lines to ensure that they are not kinked, dented or rubbing together and have installed the compressor compartment access panel? (see pg. 9)**
- ☐ **Have you checked and verified the voltage of the receptacle you are going to use for power and the voltage required for the case match? (see pg. 9)**
- ☐ **Have you verified the display case switch is in the OFF position prior to plugging in to the main power source? (see pg. 9)**
- ☐ **Have you reviewed safety warning labels and verified all are present and in good condition?**

After powering-up the case, be certain that all of the steps listed below have been completed to ensure proper case functionality, safety and compliance with warranty terms.

- 1. Check case temperature and adjust controller as needed. All display case connections comply with the information/instructions?**
- 2. Store the installation manual in the vicinity of the display case itself to where it can be accessed and consulted by all members of staff involved in the use of the refrigerator display case.**
- 3. Before placing food in the display case, allow the case to operate for approximately two (2) hours and ensure the case is at the proper temp before loading.**

AIRFLOW & DEFROST

AIRFLOW & PRODUCT LOAD

Hillphoenix cases provide maximum product capacity within the refrigerated air envelope. Please keep products within the appropriate load limit.

It is important that you do not overload the food product display so that it impinges on the airflow pattern (Fig. 17). Overloading will cause malfunction and the loss of proper temperature levels. The designed load limit is 3" above the deck for critical temperature products and 6" for non-critical temperature products. *For full technical reference drawings with load limit lines refer to page 5.*




Fig. 17 Airflow pattern

WARNING

Always keep product within the designated air curtain. Failure to do so may result in case malfunction and product losing proper temperature, resulting in sub-standard operation and increased chances of food contamination.

CAUTION

Proceed to the loading only once the display case has reached the proper temperature setting.

DEFROST

Cases are equipped with Temperature Terminated Off-Time defrost.

The defrost cycle is very important in that it ensures correct operation of the case. It is activated and controlled by the thermostat which temporarily stops the condensing unit, allowing the evaporator to shed the build-up of ice. The control-

lers synchronize the defrost between condensing units via the auxiliary ports.

DANGER

FLAMMABLE

DANGER - Risk of Fire or Explosion. Flammable Refrigerant Used. Do Not Use Mechanical Devices To Defrost Refrigerator. Do Not Puncture Refrigerant Tubing.



WARNING

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance, or an operating electric heater).

Do not pierce or burn.

Be aware that refrigerants may not contain an odor.

CASE CLEANING

A periodic cleaning schedule should be established to maintain proper sanitation, insure maximum operating efficiency, and avoid the corrosive action of food fluids on metal parts that are left on for long periods of time. We recommend cleaning once a week. Further suggestions for case cleaning include the following:

- To avoid shock hazard, be sure all electrical power is turned off before cleaning. In some installations, more than one disconnect switch may have to be turned off to completely de-energize the case.
- All surfaces pitch downward to a deep-drawn drain trough, funneling liquids to the center of the case where the waste outlet is located for easy access. Check the waste outlet to insure it is not clogged before starting the cleaning process and avoid introducing water faster than the case drain can carry it away.
- To clean the LED luminaires, shut off the lights in the case, then wipe the luminaires down with a soft, damp cloth. Avoid using harsh or abrasive cleaners as they may damage the lights. Be certain that the luminaires are completely dry before re-energizing.
- Clean from top to bottom when cleaning the display case to avoid cross contamination.
- If any potentially harmful cleaners are used, be certain to provide a temporary separator (e.g., cardboard, plastic wrap, etc.) between those cases that are being cleaned and those that may still contain product.
- Avoid spraying any cleaning liquids directly on the electrical connections.
- Allow cases to be turned off long enough to clean any frost or ice from coil and pans.
- Remove toekick and clean underneath the case with a broom and a long-handled mop. Use warm water and a disinfecting cleaning solution when cleaning underneath the cases.



DANGER

SHOCK HAZARD

Always disconnect power to case when servicing or cleaning. Failure to do so may result in serious injury or death.



CAUTION

Use specific products for disinfection and cleaning: use soft, non-abrasive sponges and rags!

Fans and Pressure Plate

1. Disconnect power to the case and wait for fans to come to a complete stand-still.

2. To reach the fans and pressure plate first remove the base deck with help of the pre-drilled access lift supplied (Fig. 18). **Note: It is recommended that more than one person lift the deck.**




Fig. 18 Base deck pre-drilled access lift

3. To access the underside of the fans first remove the screws on the top ends and front sill of the pressure plate cover (Fig. 19). Lift the pressure plate by use of the provided lift handles (Fig. 19). There are hinges shared between the pressure plate and coil covers. **Note: It is recommended that more than one person lift the pressure plate.** The topside of pressure plate will rest against the topside of the coil cover, exposing the underside of the pressure plate and fans (Fig. 19).
4. Clean as necessary. Use a spray bottle filled with an approved mild detergent and warm water.
5. Be sure to move the pressure plate back to its original position after cleaning and/or inspection is complete.



CAUTION

Only lift the pressure plate and/or coil cover for a qualified inspector or a trained service provider. Failure to do so may result in damage to the refrigerant system.



DANGER

When carrying out cleaning work or maintenance on the condensing unit it is essential to disconnect the machine and all its accessories from the main power.



DANGER

DANGER OF BURNS

Be careful of the elements inside the condensate dissipator pan: this operates at high temperature.




Fig. 19 Pressure plate, coil cover, and screws

Coil Inspection

1. Disconnect power to the case and wait for fans to come to a complete stand-still.
2. Disconnect the fan cord before accessing the screws. Remove the top two screws at both ends of the coil cover (Fig. 19), as well as the screws from the top ends and front sill of the pressure plate cover (Fig. 19). **Be sure to save the removed screws for reassembly.**
3. Carefully, without bending the sheet metal cover, lift up the bottom edge of the pressure plate to expose the evaporator coil.

WARNING

Exercise extreme caution when working in a case with the pressure plate removed. The coil contains many sharp edges that can result in severe cuts to the hands and arms.

WARNING

Exercise extreme caution when working in a case with the coil cover removed. The coil contains many sharp edges that can result in severe cuts to the hands and arms.

4. Clean as necessary. Use a spray bottle filled with an approved mild detergent and warm water. **This location should be accessed by qualified personnel only.**
5. Be sure to screw the coil cover back to its original position after cleaning and/or inspection is complete.

CAUTION

Always be sure to move the pressure plate and screw the coil cover back to their original position after the cleaning and/or inspection is complete. Failure to do so may result in damage to the refrigerant system.

! DANGER

FLAMMABLE

DANGER - Risk of Fire or Explosion. Flammable Refrigerant Used. Do Not Use Mechanical Devices To Defrost Refrigerator. Do Not Puncture Refrigerant Tubing.



Condenser Air Intake Filter

Clean and remove the debris from the condenser air intake filter monthly. If filter is not cleaned regularly the head pressure will rise and cut all power off to the compressor by means of the pressure switch.

The filter will either have a slide-out screen or pull-off magnetic application. **Note: Prior to cleaning, be sure to remove the filter from the case completely and move to a distance far enough away that no debris will come in to contact with the case or the product inside.** Both can be cleaned with an air hose and/or rinsed with water. Be sure to remove all debris and wait until completely dry before placing back on to the case. (Top mounted compressors will not have an air intake filter.)

! CAUTION

Be sure to clean the condenser air intake filter monthly. Failure to do so may result in loss of normal compressor functions and case damage.

Cleaning Condensate Dissipator Pan

Inspect the dissipator pan (Fig. 20) at least once every six months. Ensure you disconnect the electrical power supply and make sure you DO NOT touch the elements as they reach high temperatures (necessary for evaporation inside the pan).




Fig. 20 Cleaning the dissipator pan and condensing unit

Cleaning Condenser

The condensers used on the condensing units gather dust and dirt and must be cleaned regularly. Under normal working conditions this task must be executed at least once a month using a soft-bristled brush and a vacuum cleaner. A dirty condenser will reduce the display case performance: it will also result in increased energy consumption. (Fig. 21)

UNSCHEDULED CASE MAINTENANCE

Unscheduled maintenance concerns all those tasks that cannot normally be carried out by the routine user as specified. Such tasks require qualified personnel with specific technical skills (e.g. refrigeration system specialists, electricians etc.) and must be carried out at least once a year. See the scheduled maintenance table for a list of the main tasks (Fig. 21).

If inspection reveals any rust, cracks and etc...it will be necessary to carry out repairs and/or replacement of parts so that the case meets code and the display case is in prime operating condition.

To enhance safety, it is recommended that you always seek the advice of a specialized technician before carrying out any repair work.

PARTS SUBJECT TO WEAR & SPARE PARTS

Most spare parts carry clear, complete ID information. It is important that the refrigerated case parts be replaced by analogous parts of equivalent safety and quality: to order spare parts please contact Hillphoenix, stating the case model and serial number, found in this manual or on the case ID plate, and provide a description of the component and the desired quantity. Refer to the Parts section in the back of the manual for parts ordering and to identify parts that may need to be replaced.



CAUTION

Do not pressure wash equipment as damage to electrical components may result.

SCHEDULED MAINTENANCE TABLE

Maintenance	Weekly	Monthly	Half Yearly	Yearly
Cleaning case	✓			
Cleaning gas condenser		✓		
Case visual check	✓			
Safety labels visual check	✓			
Check electric system				✓
Check water drainage system.			✓	
Check refrigeration system				✓
General inspection				✓

Fig. 21 Recommended cleaning schedule

TROUBLESHOOTING

INSTRUCTIONS FOR PERSONNEL

In the Event of General Emergency

Immediately inform those in the vicinity of the perceived danger, gesticulating if necessary; cut the electrical power to the cabinet.

In the Event of Fire

In the event that the refrigerated case catches fire or is involved in a fire it is possible to use an extinguisher with a powder-type or CO2 extinguishing agent.

Resetting the Case

To restore normal operation it is necessary to eliminate all the causes of the emergency situation; if necessary repair or replace damaged parts.

Note: If safety devices are tripped it will be necessary to identify the cause before continuing work.



CAUTION

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.



CAUTION

R-290 flammable refrigerant in use. Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation operating and maintenance instructions thoroughly before installing or servicing this equipment.



DANGER

FLAMMABLE

DANGER - Risk of Fire or Explosion. Flammable Refrigerant Used. Do Not Use Mechanical Devices To Defrost Refrigerator. Do Not Puncture Refrigerant Tubing.



TABLE OF FAILURES AND SHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
The refrigerated cabinet does not work.	1) the mains circuit breaker is set to OFF; 2) the power line between refrigerated cabinet and power socket is faulty; 3) the switch on the refrigerated cabinet control panel is not switched on.	1) turn the mains power on; 2) make sure the plug is inserted properly in the socket; 3) turn the power switch on the refrigerated cabinet panel to ON.
The refrigerated cabinet does not cool enough.	1) the temperature thermostat is adjusted incorrectly; 2) the refrigerated cabinet has been filled too much 3) the condensing unit is clogged with dust 4) the evaporator is covered in ice	1) reprogram the temperature thermostat; 2) remove goods and observe the maximum load level; 3) clean the condensing unit with a soft-bristled brush and vacuum cleaner 4) carry out a defrost cycle.
The refrigerated cabinet cools too much.	1) the temperature thermostat is adjusted incorrectly.	1) reprogram the temperature thermostat;
The refrigerated cabinet runs continuously.	1) the temperature thermostat is adjusted incorrectly; 2) the refrigerated cabinet has been filled too much and is preventing correct air circulation.	1) reprogram the temperature thermostat; 2) remove goods and observe the maximum load level.

FAILURES AND SHOOTING

Failures

In the event of a failure of mechanical/electrical/refrigeration parts the initial safety conditions must be restored immediately by replacing or repairing such faulty parts.

SAFETY DEVICES

 WARNING

It is absolutely forbidden for the user to tamper with safety devices. Before using the refrigerated case check that mechanical safety covers are properly in place. Any tampering shall render the warranty null and void and exonerate Hillphoenix from any liability with regard to users of the refrigerated case.

Only maintenance personnel may carry out maintenance tasks involving safety devices. These tasks are listed below.

SAFETY DEVICE	SCOPE OF INTERVENTION	ACTION
Incorporated over-pressure cut-out	On incorporated condenser unit compressor	Cuts the electrical power of the compressor if the pressure of the refrigerant rises above the safety limits.
Fixed cover on electrical control panel. Remove only with aid of tools	Electrical control panel	Prevents access to live parts. Electrical danger warning sign applied (see "DESCRIPTION OF DANGERS AND RISKS RESIDUAL")
Fixed safety gratings. Remove only with aid of tools	On evaporator fans.	Prevents access to fans when they are running or slowing down to a stop.

DESCRIPTION OF DANGERS AND RISKS RESIDUAL

Residual Dangers

Dangers that have not been reduced/eliminated with the safety measures adopted on the refrigerated case can nevertheless be reduced/eliminated as long as users apply proper managerial practices. Users must:

- ☐ Ensure that all safety warning and labels are always in good condition; inspect them periodically and have them replaced whenever necessary.
- ☐ Do not install any spare parts that are not identical to the originals or of equivalent performance.
- ☐ Do not carry out any modifications or structural work without approval from Hillphoenix or a qualified field service technician.
- ☐ Should the refrigerated case be dented, inspect the structure visually or have qualified personnel carry out an inspection.

After a long period of disuse have a qualified field service technician carry out an inspection of the case to check that it is in good condition and working properly.

Residual Risks

While the refrigerated case has been designed to ensure maximum safety, there nevertheless remain some residual risks. Hillphoenix has identified the main **dangers and residual risks for users and maintenance personnel** as follows in chart below:

SCHEDULED MAINTENANCE TABLE

DESCRIPTION OF RESIDUAL RISK	CAUSE	SAFETY MEASURES
Danger of falls in area surrounding the cabinet	Presence of: stairs, columns etc. and/or slippery floors and objects and/or work tools	Mark out the relevant zones and highlight them with warning signs and symbols (e.g. yellow/black striped marker tape on stairs etc.) that are visible during both routine use and maintenance.
Danger of objects accidentally falling	Haphazard storage of tools/objects.	Use tool boxes in work areas. Ensure personnel are trained.
Danger of injury to hands, arms, legs and head	During cleaning and maintenance there may be objects or parts of the cabinet protruding from the case itself (e.g. glass covers open during cleaning)	Mark out the work area with appropriate barriers. Always use the recommended personal safety devices.
Risk of refrigerating gas leaks	Accidental damage to pipes	Immediate shutdown of case operation. Disconnect electrical power supply. Contact a service technician.

SAFETY DEVICES & SERVICE

REFRIGERANT

This piece of equipment uses a R-290 Refrigeration system. This equipment has been clearly marked on the serial tag the type of refrigerant that is being used. There is also a warning labels stating that the unit contains R-290 refrigerant.

No smoking or open flames when servicing this equipment. If needed, use a CO2 or dry=power type fire extinguisher

Only authorized service technician, certified in R-290 system should service this equipment.

MANIFOLD SET

A R-134A manifold set can be used for servicing this equipment.

REFRIGERANT RECOVERY

Follow all national and local regulations for R-290 refrigerant recovery.

LEAKING CHECKING AND REPAIR

Leak check an R-290 system the same way you would an R-134a or R-404A system with the following exceptions.

1. Do not use a Halid leak detector on a R-290 system.
2. Electronic leak detector must be designated specifically for combustible gas.

Use of a bubble solution or an ultrasonic leak detector are acceptable.

When repairing a leak, it is recommended using oxygen free dry nitrogen with a trace gas not exceeding 200PSI.

When accessing an R-290 system, proper charge is to be weighed into the system and the system is to be leak checked afterwards.

The R-290 equipment must have red process tubes and other devices through which the refrigerant is serviced, such as any service port. This color marking must remain on the equipment. If marking is removed, it must be replace and extend at least 2.5 centimeters (1") from the compressor.

- Ensure the system is sealed and leak checked
- Evacuate system to a minimum 500 micron
- Weigh in correct charge
- Leak check the system again
- Bleed the refrigerant from the high side hose to the low side hose
- Disconnect the hoses
- Remove line taps

DANGER

FLAMMABLE

DANGER - Risk of Fire or Explosion. Flammable Refrigerant Used. Do Not Use Mechanical Devices To Defrost Refrigerator. Do Not Puncture Refrigerant Tubing.



CAUTION

It is highly recommended that a technician servicing a case with HC refrigerant is aware of safety considerations and maintenance procedures on how to safely handle flammable refrigerants.

CAUTION

Component parts shall be replaced with like components. Service work shall be done by factory authorized service personnel, so as to minimize the risk of possible ignition due to incorrect parts or improper service.

CHARGING

Follow the charge amount specified on the data tag. It is recommended to use the shortest hoses possible to prevent under-charging.

SERVICE PERSONNEL INFORMATION

1. Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, the items below shall be completed prior to conducting work on the system.
2. Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapor being present while the work is being performed.
3. All maintenance staff and others working in the local area shall be structured on the nature of work being carried out. Work in confined spaces shall be avoided.
4. The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e., non-sparking, adequately sealed, or intrinsically safe.
5. If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand. A dry chemical or CO₂ fire extinguisher should be adjacent to the charging area.
6. No person carrying out work in relation to a refrigerating system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment shall be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
7. Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel externally into the atmosphere.
8. Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
9. Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment, so all

parties are advised. Initial safety checks shall include:

- a. That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- b. That no live electrical components and wiring are exposed while charging, recovering or purging the system;
- c. That there is continuity of earth bonding.

REPAIRS TO SEALED COMPONENTS

1. During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
2. Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
 - a. Ensure that the apparatus is mounted securely.
 - b. Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.

REPAIRS TO INTRINSICALLY SAFE COMPONENTS

1. Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
2. Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.
3. Replace components only with parts specified by the manufacturer. Other parts can result in the ignition of refrigerant in the atmosphere from a leak.
4. The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

DETECTION OF FLAMMABLE REFRIGERANTS

1. Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.
2. The following leak detection methods are deemed acceptable for all refrigerant systems:
 - a. Electronic leak detectors may be used to detect refrigerant leaks but, in the case of flammable refrigerants, the sensitivity might not be adequate, or might need recalibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25% maximum) is confirmed.
 - b. Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine can react with the refrigerant and corrode the copper pipework.
 - c. Examples of leak detection fluids are:
 - i. Bubble method
 - ii. Fluorescent method agents
 - d. If a leak is suspected, all naked flames shall be removed/extinguished.
 - e. If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. Removal of refrigerant shall be according to Removal and Evacuation instructions (Clause 101.DVS.9).

REMOVAL AND EVACUATION

1. When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:
 - a. Safely remove refrigerant following local and national regulations;
 - b. Purge the circuit with inert gas;
 - c. Evacuate;
 - d. Purge with inert gas;
 - e. Open the circuit by cutting or brazing.
2. The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable

refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.

3. For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
4. Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

CHARGING PROCEDURES

1. In addition to conventional charging procedures, the following requirements shall be followed:
 - a. Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
 - b. Cylinders shall be kept in an appropriate position according to the instructions.
 - c. Ensure that the refrigerating system is earthed prior to charging the system with refrigerant.
 - d. Label the system when charging is complete (if not already).
 - e. Extreme care shall be taken not to over-fill the refrigerating system.
2. Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

DECOMMISSIONING

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its details. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task commences.

1. Become familiar with the equipment and its operation.
2. Isolate the system electrically.

3. Before attempting the procedure, ensure that:
 - a. Mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - b. All personal protective equipment is available and being used correctly;
 - c. The recovery process is supervised at all times by a competent person;
 - d. Recovery equipment and cylinders conform to the appropriate standards;
 - e. Pump down refrigerant system, if possible.
 - f. If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
 - g. Start the recovery machine and operate in accordance with instructions.
 - h. Do not overfill cylinders (no more than 80% volume liquid charge).
 - i. Do not exceed the maximum working pressure of the cylinder, even temporarily.
 - j. When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
 - k. Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.
4. Equipment shall be labeled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

RECOVERY

1. When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
2. When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
3. The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all

appropriate refrigerants including, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

4. The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
5. If compressors or compressors oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerator does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

Hillphoenix[®]

a **DOVER** company

Contact the Service Parts Department at:

1-844-HPX-PART (1-844-479-7278)

or

SpecialtyParts@doverfoodretail.com

Provide the following information about the part you are ordering:


- **Model number and serial number*** of the case for which the part is intended.
- **Length of the part** (if applicable).
- **Color of part** (if painted) or color of polymer part.
- **Whether part is for left or right-hand application.**
- **Quantity**

***Data tag is located on the left end exterior panel or top interior of the case.**

If the parts are to be returned for credit, contact the Parts Department. Do not send parts without authorization.

A1-A11	Wiring Information
B1-B4	Carel Easy/ Carel MPXzero Operating Instructions
C1	Sporlan Pressure-Temperature Chart (R-290)
D1	Parts List

A1: WIRING DIAGRAM




DESIGN NOTES:


1. Shelving option: up to 4 shelves shown. Refer to job paperwork for actual quantity.
2. Extn. cord option: 2 Extension cord option shown consult job paperwork for actual usage

DRAWING #:	JOB #:	 P.O. BOX 478 KEOSAUQUA, IA 52565 PHONE: (319)293-3777 FAX: (319)293-3776	HILLPHOENIX LIGHTING HARNESS COLUMNS:1, PS:1 TOP:1HQ,SHELF:4SOMAX	CASE #:	OF:	SIZE:	VOLTS:
132838				-	-	A	-
DATE:	ORDER #:			PAGE #:		OF:	PHASES:
06/16/2025				1			-
REVISION #:	DRAWN BY:						HERTZ:
0	NITHEEN A				-		
REV DATE:06/16/2025	REV BY: NITHEEN A	REV DESCRIPTION: 1.RELEASED.					


A2: WIRING DIAGRAM




A3: WIRING DIAGRAM




A4: WIRING DIAGRAM




A5: WIRING DIAGRAM




A6: WIRING DIAGRAM




A7: WIRING DIAGRAM




A8: WIRING DIAGRAM




A9: WIRING DIAGRAM




A10: WIRING DIAGRAM



A11: WIRING DIAGRAM



B2: CAREL MPXzero OPERATING INSTRUCTIONS



Digital outputs	NO1, NO2, NO3, NO4	NO1 (2 hp): EN60730-106/A, 250 Vac; EN60730-10A, 250 Vac; 8FLA, 48VRA, 250 Vac; Pilot duty, B300, 250 Vac; NO2 (8 A): EN60730-43/A, 240 Vac; EN60730-43/A, 240 Vac; 12FLA, 240 Vac; Pilot duty, C300, 240 Vac; NO3, NO4 (5 A): EN60730-51/A, 240 Vac; EN60730-5A, 240 Vac; 1FLA, 6FLA, 240 Vac; Pilot duty, C300, 240 Vac; NO2+NO3+NO4 max 12A
Cable lengths	Analogue inputs, digital inputs/outputs, probe	< 10 m
Conformity	BMS and fieldbus serial interface - UVD directive and UL sections 29 & 30	IEC/RN/UL 60730-1, CSA 660730-1, IEC 60335-1
	Electromagnetic compatibility - EMC directive	IEC/RN 61000-6-1, IEC/RN 61000-6-2, IEC/RN 61000-6-3, IEC/RN 61000-6-4
	Applications with flammable refrigerant gases	IEC/RN/UL 60335-2-40 (clauses 22.1.16 & 22.1.18 & 22.1.19), IEC/RN/UL 60335-2-40 (clauses 22.1.16 & 22.1.18 & 22.1.19), IEC/RN/UL 60079-15 (clauses 17 & 19, applicable to the relays according their type. Acceptability should be always verified and judged in the final application).
	Wireless compliance	RED directive, FCC (section 15, subsection B), IC.


IMPORTANT WARNINGS

The CAREL product is a state-of-the-art product, whose operation is specified in the technical documentation supplied with the product or can be downloaded, even prior to purchase, from the website www.carel.com. The customer (manufacturer, developer or installer) is responsible for the correct use of the product and for the safety of the installation of the product in order to reach the expected results in relation to the specific final installation and/or equipment. Failure to complete such operations, which are required/indicated in the user manual, may cause the final product to malfunction; CAREL accepts no liability in such cases. The customer must only use the product in the manner described in the documentation relating to the product. The liability of CAREL in relation to its products is specified in the CAREL general contract conditions, available on the website www.carel.com and/or by specific agreements with customers.

Disposal of the product: the appliance (or the product) must be disposed of separately in accordance with the local waste disposal legislation in force.

Physical specifications	Technical specifications
Cave temperature	Self-extinguish polycarbonate
Ball pressure test	125 °C
Ingress protection	IEC
Front cleaning	Use soft, non-abrasive cloth and neutral detergent. Rear: IP20. Front: IP65
Operating temperature	-20/60 °C, <90% RH non-condensing
Storage temperature	-20/85 °C, <90% RH non-condensing
Nominal power	100-240 Vac
Supply voltage	90-264 Vac
Operating power	50/60 Hz
Input frequency	50/60 Hz
Input delay	200 mW
Min power consumption	200 mW
Clock	Precision: 20 ppm at 25 °C; 100 ppm in the range -20/60 °C; date/time retention with unpowered control up to 2 years (20160 °C).
Software class and structure	A
Environmental structure	2
Class protection	To be incorporated in class II or I appliances
Type of action	1.C
Rated impulse voltage	100-240 Vac; input and relay outputs: 2.5 kV
Surge immunity category	100-240 Vac; input and relay outputs: 1
Control device	Device to be incorporated
Terminal block	NO1, C1, NO2, NO3, NO4, L, N, mm²
	Plug in male-female 30-12 AWG / 0.05-3.3 mm²
	Plug in male-female 30-17 AWG / 0.05-2 mm²
	Plug in male-female 30-17 AWG / 0.05-1 mm²
	Plug in male-female 30-17 AWG / 0.05-1 mm²
	FieldBus: JST ZH connector 32-26 AWG / 0.03-0.13 mm²

ALLARMI
Al verificarsi di un allarme, l'icona ALARM diventa rossa e il terminale utente visualizza il codice corrispondente all'allarme.
Def. Min. Max. UOM.
In Tipo di unità: 0 0 1 -
Sn Numero secondario nella rete locale: 0 0 9 -
H0 Indirizzo seriale o di rete Main/Secondary: 199 0 199 -
H3 Protocollo porta seriale BMS: 1 0 1 -
/P1 Tipo sonda gruppo (S1, S2, S3): 1 0 1 -
1 = NTC Standard Range -50/70°C



Backlit buttons/icons	On	Flashing
Control panel	Active	Timings active
Evaluator	Active	-
Lights	On	-
Defrost	Active	Waiting
Service	Maintenance request	-
Alarm	Acknowledged alarm	Active alarm
°C	Unit of measure °C	-
°F	Unit of measure °F	-

Standard product configuration, see the user manual for other configurations.

KeyPad	Button	Description
UP - DOWN	↑ ↓	Increment/decrement the value
DOWN	↓	Increment/decrement the value
PRG	⊙	Enter programming mode or return to previous level without saving

ALARMS
When an alarm occurs, the ALARM icon turns red and the user terminal displays the corresponding alarm code.
Code Description Def Min Max UOM
rE Immediate alarm from external contact
E1 Control probe
E2 Delayed alarm from external contact
E3 Door open for too long
E4 Real time clock not updated
E5 Real time clock not updated
E6 Real time clock not updated
E7 Real time clock not updated
E8 Real time clock not updated
E9 Real time clock not updated
E10 Real time clock not updated
E11 Real time clock not updated
E12 Real time clock not updated
E13 Real time clock not updated
E14 Real time clock not updated
LO Low temperature
HI High temperature
LO2 Low temperature
HI2 High temperature

ATTENTION
This label is part of the product and should be kept near the control for quick reference.
The control shall not be used for purposes other than those for which it was designed, in particular it can't be used as a safety device.
In case of failure contact an authorized service center.
The control must not be opened.
Check the power supply voltage before installing.
Do not touch the control terminals. Do not expose to liquids or steam and avoid sudden temperature changes that might cause condensation.
Disconnect the power supply before any kind of maintenance.
Observe the maximum current output value for each relay (see "Technical specifications" section).
Do not apply dangerous voltage to the SELV connection terminals (see "Technical specifications" section).
Observe the maximum current output value for each relay (see "Technical specifications" section).
Separate the probe and digital input cables from output and power cables. Never run power cable and signal cables in the same conduit.

B4: CAREL Easy Controller

ITA Visualizzazione e funzioni

Durante l'installazione il controllo visualizza a display i valori della sonda impostata con il parametro A (=1 sonda ambiente di default, =2 seconda sonda, =3 terza sonda). Inoltre sul display appaiono i LED che indicano l'attivazione delle funzioni del controllo (vedi Tab. 1), mentre i 3 tasti permettono di attivare/disattivare alcune funzioni (vedi Tab. 2).

LED e funzioni associate

icona	funzione	normale funzionamento	start up
	accesso	spento	richiesto ON
	accesso	spento	richiesto ON
	accesso	spento	richiesto ON
	uscita access	uscita spenta	ON
	tutti	nessun allarme	ON
	RTC presente e abilitato, ed è stata impostata almeno 1 fascia oraria	-	ON se RTC presente

Tabella attivazione funzioni tramite i tasti - mod. S, X, Y, C

tasto	pressione del singolo tasto	pressione combinata	start up
	più di 3 s. alterna stati ON/OFF	Premuti insieme attivano/disattivano ciclo continuo	-
	più di 3 s. attiva/disattiva defrost	-	Premuti insieme attivano/disattivano defrost
	- 1 s.: visualizza i parametri di impostazione set point (inserire password "22") - 10 s.: visualizza i parametri di impostazione parametri (inserire password "22") - 10 s.: attiva/accollega (buzzer)	-	per 1 s. visualizza cod. vers. firmware per 1 s. RESET banco EZI corrente

Tabella funzioni tasti - variante mod. M

tasto	normale funzionamento	start up
	selezione rapida sonda visualizzata	Premuto insieme a "set" attiva procedura RESET parametri

Impostazioni del set point (valore di temperatura desiderato)

- premere per 1 s. SET, dopo alcuni istanti il valore impostato lampeggia;
- aumentare o diminuire tale valore con UP o DOWN;
- premere SET per confermare il nuovo valore.

ON/OFF dello strumento

Premere per 1 s. SET in questa condizione gli algoritmi di regolazione e defrost sono disabilitati e lo strumento alterna la visualizzazione a display del messaggio "OFF" a quella della temperatura della sonda impostata.

Sbrinatorio manuale (solo per mod. S, X, Y e C)

Premere per più di 3 s. DOWN (si attiva solo se sussistono le condizioni di temperatura).

Ciclo continuo (solo per mod. S, X, Y e C)

Premere contemporaneamente per più di 3 s. UP e DOWN.

Selezione rapida sonda visualizzata (solo per mod. M)

Premere rapidamente DOWN per selezionare la sonda da visualizzare temporaneamente.

Accesso e modifica parametri tipo F (frequenti) e tipo C (configurazione)

1. premere SET per 3 s (sul display compaiono "PS");
 2. per accedere al menu parametri di tipo F e C digitare la password "22" (o: UP/DOWN);
 3. per visualizzare/modificare i valori dei parametri premere SET (senza digitare la password);
 4. navigare all'interno dei menu parametri UP/DOWN;
 5. premere il tasto di modifica (si tiene con il dito indice del pollice);
 6. premere il tasto di conferma (si tiene con il dito indice del pollice).
- Per uscire dal menu senza salvare i valori modificati (uscita per time out) non premere alcun tasto per almeno 60 s.

Normative di sicurezza

conforme alle Normative europee in materia. Precauzioni d'installazione:

- i cavi di collegamento devono garantire l'isolamento fino a 90 °C;
 - per le versioni 12 Vdc. utilizzare trasformatori Classe II. Per il rispetto delle normative EN 61000-4-4, EN 61000-4-5, EN 61000-4-11, EN 61000-4-6, EN 60730-1, il trasformatore deve essere uno dei modelli indicati (vedi Lista Prezzi CAREL).
 - Per le versioni 12 Vdc./dc. non essendo possibile garantire il doppio isolamento tra i connettori di alimentazione e le uscite relè, si raccomanda di utilizzare carichi alimentati solamente in bassissima tensione di sicurezza (fino a 42 V nominali di valore efficace);
 - prevedere almeno 10 mm di distanza tra i connettori e parti conduttive vicine;
 - collegamenti degli ingressi digitali e analoghi inferiori a 30 m di distanza, adottare le adeguate misure di separazione dei cavi per il rispetto delle normative suddette.
- Bloccare bene i cavi di connessione delle uscite per evitare contatti con parti in bassissima tensione di sicurezza.

Certificazioni solo per POEZ

Applicazioni con gas refrigeranti infiammabili: IEC/EN/UL 60335-2-24 (clausule 22.09, 22.10) - IEC/EN/UL 60335-2-40 (clausule 22.16, 22.17) - IEC/EN/UL 60335-2-89 (clausule 22.07, 22.08, 22.09) per gas R60, R60A, R-1234ze gasifica e IEC/EN/UL 60079-15 (clausule 17 e 19, applicabili al relè in base alla loro tipologia. L'accettabilità deve essere sempre verificata e validata nella applicazione finale).

ENG Display and functions

During normal operation, the controller displays the value of the probe set using parameter A (=1 ambient probe, default =2 second probe, =3 third probe). In addition, the display has LEDs that indicate the activation of the control functions (see Table 1), while the 3 buttons allow you to activate/deactivate some functions (see Table 2).

FRE Description

Il controller visualizza a display i valori della sonda impostata con il parametro A (=1 sonda ambiente di default, =2 seconda sonda, =3 terza sonda). Inoltre sul display appaiono i LED che indicano l'attivazione delle funzioni del controllo (vedi Tab. 1), mentre i 3 tasti permettono di attivare/disattivare alcune funzioni (vedi Tab. 2).

LED e funzioni associate

- POEZCEZ*, indicate pour la gestion d'unités frigorifiques statiques, sans ventilateur sur l'évaporateur, fonctionnant à des températures supérieures à 0°C;
- POEZCEZ*, indiqués pour la gestion d'unités frigorifiques ventilées à basse température;
- POEZCEV, X*, indiqués pour la gestion d'unités frigorifiques statiques, sans ventilateur, fonctionnant à basse température;
- POEZCEM*, solution pour mesurer simplement la température

Note: mod. Y= relés reliés électriquement à l'intérieur entre eux, mod. X= relés indépendants.

Affichage et fonctions

Pendant le fonctionnement normal le contrôle affiche sur l'écran la valeur de la sonde réglée au paramètre A (=sonde air ambiant par défaut, =2 deuxième sonde, =3 troisième sonde). De plus sur l'écran apparaissent les LED qui indiquent l'activation des fonctions de contrôle (voir Tab. 1), alors que les trois touches permettent d'activer/désactiver certaines fonctions (voir Tab. 2).

icone	fonction	fonctionnement normale	blink	start up
	accès	éteint	requis	ON
	accès	éteint	requis	ON
	accès	éteint	requis	ON
	sortie accès	sortie éteinte	-	ON
	tous	aucun alarme	-	ON
	horloge	RTC absent ou désactivé, ou une tranche horaire au moins à dé régler	-	ON si RTC présent

Tableau activation fonctions à l'aide des touches - mod. S, X, Y, C

touche	simple pression de la touche	pression combinée	start up
	up ON/OFF	Appuyées ensemble activer/désactiver cycle continu	-
	down defrost	plus de 3 s. active/phase ON/OFF	pendant 1 s. affiche cod. vers. firmware pour 1 s. RESET banc EZI courant
	set mute	- 1 s.: afficher permet de régler set point - plus de 3 s.: accès au menu réglages paramètres (entrer mot de passe "22") - 10 s.: alarme accouplée (buzzer)	-

Tableau fonctions touches - variante mod. M

touche	fonctionnement normale	start up
	sélection rapide sonde affichée	pendant 1 s. affiche cod. vers. firmware

Réglages du set point (valeur de la température désirée)

- appuyer pendant 1 s. sur SET, quelques instants après la valeur réglée s'affiche;
- augmenter ou diminuer la valeur avec UP ou DOWN;
- appuyer sur SET pour confirmer la nouvelle valeur.

ON/OFF de l'instrument

Appuyer pendant plus de 3 s. sur DOWN (l'écran ne s'allume pas) les algorithmes de régulation et de dégivrage sont désactivés et l'instrument alterne l'affichage de l'écran du message "OFF" et l'affichage de la température pré-réglée de la sonde.

Dégivrage manuel (seulement pour mod. S, X, Y e C)

Appuyer pendant plus de 3 s. sur DOWN (l'écran ne s'allume pas) les algorithmes de régulation et de dégivrage sont désactivés et l'instrument alterne l'affichage de l'écran du message "OFF" et l'affichage de la température pré-réglée de la sonde.

Cycle continu (seulement pour mod. S, X, Y e C)

Appuyer en même temps pendant plus de 3 s. sur UP et DOWN.

Sélection rapide sonde affichée (seulement pour mod. M)

Appuyer rapidement DOWN pour sélectionner la sonde à afficher temporairement.

Accès et modification paramètres type F (fréquent) et type C (configuration)

1. appuyer sur SET pendant 3 s (sur l'écran apparaît "PS");
2. pour accéder au menu paramètres de type F et C entrer le mot de passe "22" (en utilisant UP/DOWN);
3. pour accéder/modifier les valeurs des paramètres appuyer sur SET (sans devoir entrer le mot de passe);
4. pour accéder/modifier les valeurs des paramètres appuyer sur SET, ensuite sur UP/DOWN et enfin sur SET pour confirmer la modification (on retourne ainsi au menu paramètres).
5. pour quitter définitivement toutes les valeurs modifiées (sortie time out) ne pas appuyer sur aucun bouton pendant au moins 60 s.

Normes de sécurité

- conformes aux Normes européennes pertinentes. Précautions d'usage:
 - les câbles de connexion doivent garantir l'isolation jusqu'à 90 °C;
 - pour les versions 12 Vdc. utiliser transformateurs Classe II. Pour respecter les normes de sûreté (surge), le transformateur doit être un des modèles indiqués (voir catalogue CAREL). Pour les versions 12Vdc./dc. une double isolation ne peut être garantie entre l'alimentation et les relés de sortie, il est conseillé d'utiliser uniquement avec des charges basse tension (jusqu'à 42 V nominal efficace);
 - laisser au moins 10 mm de distance entre le boîtier et les parties conductives voisines;
 - connexions des entrées analogues inférieures à une distance de 30m; adopter les mesures de séparation appropriées des câbles pour le respect des normes de sûreté.
- Bloquer avec soin les câbles de connexion des sorties pour éviter les contacts avec les éléments sous Tels Base tension de sécurité.

Certifications pour POEZ uniquement

Applications avec des gaz réfrigérants inflammables: CEI/EN/UL 60335-2-24 (clauses 22.09, 22.10) - CEI/EN/UL 60335-2-40 (clauses 22.16, 22.17) - CEI/EN/UL 60335-2-89 (clauses 22.07, 22.08, 22.09) pour les gaz R60, R290, R60A, R-1234ze. IEC/EN/UL 60079-15 (articles 17 et 19, applicables aux relés en fonction de leur type. L'acceptabilité doit toujours être vérifiée et jugée dans l'application finale).

GER Beschreibung

POEZ* und POEZV* (Modelle S, C, M, Y, X) umfasst eine Baueinheit elektronischer Mikroprozessor-Steuerung mit LED-Anzeige für die Ansteuerung von Kälteanlagen (Kühlfrequenz und Kühlmittel). POEZ* Regelt sich mit Standard-Abschle, automatische POEZV* - Baueinheit werden nur für Bauanforderungen mit herkömmlichen Kältemitteln entwickelt. Zertifizierung nach EN 60335-2-24 (Klauseln 22.09, 22.10), EN 60335-2-40 (Klauseln 22.16, 22.17), IEC/EN 60335-2-89 (Klauseln 22.07, 22.08, 22.09) für Gase R60, R60A, R-1234ze gasifiziert und IEC/EN 60079-15 (Klauseln 17 und 19, anwendbar auf Relais in Abhängigkeit von ihrer Typen. Die Akzeptanz muss immer überprüft und in der Anwendung bestätigt werden).

ESP Descripción

El controlador visualiza por LED realíe los valores de la sonda instalada con el parámetro A (=1 sonda ambiente de predi-ambiente de default, =2 segunda sonda, =3 tercera sonda). Además, en el display aparecen los LEDs que indican la activación de las funciones del control (ver Tab. 1), mientras que las 3 teclas permiten activar/desactivar algunas funciones (ver Tab. 2).

LED y funciones asociadas

- POEZCEZ*, indicados para la gestión de unidades frigoríficas estáticas, carentes de ventilador en el evaporador, que funcionan con temperaturas por encima de 0°C;
- POEZCEZ*, indicados para la gestión de unidades frigoríficas ventiladas a baja temperatura;
- POEZCEV, X*, indicados para la gestión de unidades frigoríficas estáticas, carentes de ventilador, que funcionan a baja temperatura;
- POEZCEM*, solución para la medida simple de la temperatura

Note: mod. Y= relés conectados electrónicamente en el interior entre sí, mod. X= relés independientes.

Visualizaciones y funciones

Durante el funcionamiento, normal el control muestra en el display el valor de la sonda ajustada con el parám. A (=1 sonda ambiente predi-ambiente de default, =2 segunda sonda, =3 tercera sonda). Además, en el display aparecen los LEDs que indican la activación de las funciones del control (ver Tab. 1), mientras que las 3 teclas permiten activar/desactivar algunas funciones (ver Tab. 2).

icono	funcion	funcionamiento normal	parpadeo	arranque
	compresor	encendido	apagado	demanda ON
	ventilador	encendido	apagado	demanda ON
	desescarche	encendido	apagado	demanda ON
	salida apagada	salida encendida	-	ON
	todos	ninguna alarma	-	ON
	relóg	RTC presente y habilitado, y se ha ajustado al menos una franja horaria	-	ON si RTC presente

Table de activation de fonctions par medio de las teclas - mod. S, X, Y, C

tecla	funcionamiento normal	presion combinada	arranque
	presion de la tecla sola	presion combinada	-
	presion de la tecla sola	presion combinada	-
	presion de la tecla sola	presion combinada	-

Table de funciones de teclas - variante mod. M

tecla	funcionamiento normal	arranque
	seleccion rapida de sonda visualizada	pendiente a buques "set" activar el procedimiento de RESET de los parametros

Ajustes del punto de consigna (valor de temperatura deseado)

- pulsar durante 1 s. SET, después de unos instantes el valor ajustado parpadeará;
- aumentar o disminuir dicho valor con las flechas ARRIBA o ABAJO;
- pulsar SET para confirmar el nuevo valor.

ON/OFF del instrumento

Pulsar durante más de 3 s. ABAJO. En esta condición los algoritmos de regulación y desescarche son deshabilitados y el instrumento alterna la visualización en el display del mensaje "OFF" y la de la temperatura de la sonda ajustada.

Desescarche manual (sólo para mod. S, X, Y y C)

Pulsar durante más de 3 s. ABAJO (se activa sólo si subsisten las condiciones de temperatura).

Ciclo continuo (sólo para mod. S, X, Y y C)

Pulsar simultáneamente durante más de 3 s. ARRIBA y ABAJO.

Selección rápida de sonda visualizada (sólo para mod. M)

Pulsar repetidamente la tecla ABAJO para seleccionar la sonda a visualizar temporalmente.

Acceso y modificación de parámetros tipo F (frecuentes) y tipo C (configuración)

1. Pulsar SET durante 3 s (en el display aparecerá "PS");
2. Para acceder al menú de los parámetros de tipo F e C, introducir la contraseña "22" con ARRIBA/ABAJO;
3. Para acceder sólo al menú de los parámetros de tipo F e C, introducir la contraseña "22" con ARRIBA/ABAJO;
4. Para visualizar/modificar los valores del parámetro visualizado pulsar SET, y luego ARRIBA/ABAJO y finalmente SET para confirmar la modificación (se vuelve al menú de los parámetros).
5. Para guardar definitivamente todos los valores modificados y salir del menú de los parám. pulsar SET durante 3 s. Para salir del menú sin guardar los valores modificados (salida por agotamiento de tiempo) no pulsar ninguna tecla durante al menos 60 s.

Normativas de seguridad

- Conforme a las Normativas europeas de la materia. Precauciones de instalación:
 - Los cables de conexión deben garantizar el aislamiento hasta a 90 °C;
 - Para las versiones 12 V. utilizar transformadores de Clase II. Para respetar las normativas EN 61000-4-4, EN 61000-4-5, EN 61000-4-11, EN 61000-4-6, EN 60730-1, el transformador debe ser de uno de los modelos indicados (ver Lista de Precios de CAREL).
 - Para las versiones 12 Vdc./dc., no siendo posible garantizar el aislamiento doble, entre el conector de alimentación y las salidas relés, se aconseja utilizar cargas alimentadas solamente con muy baja tensión de seguridad (hasta 42V nominales de valor eficaz);
 - Prever al menos 10 mm. de distancia entre el conector y las partes conductoras próximas;
 - Conexiones de las entradas digitales y analógicas inferiores a 30 m. de distancia; adoptar las medidas adecuadas de separación de cables para respetar la normativa de la seguridad.
- Bloquear bien los cables de conexión de las salidas para evitar contactos con las partes en tensión. Tensión de seguridad.

Certificaciones solo para POEZ

Aplicaciones con gases refrigerantes inflamables: IEC/EN/UL 60335-2-24 (cláusulas 22.09, 22.10) - IEC/EN/UL 60335-2-40 (cláusulas 22.16, 22.17) - IEC/EN/UL 60335-2-89 (cláusulas 22.07, 22.08, 22.09) para gases R60, R60A, R-1234ze gasifican. IEC/EN/UL 60079-15 (cláusulas 17 y 19, aplicadas a los relés según su tipo. La aceptabilidad siempre debe ser verificada y juzgada en la aplicación final).

ROU Descripció

POEZ* y POEZV* (modelos S, C, M, Y, X) representen una gama de reguladores electrónicos con micropro-cesador con visualización por LEDs concebidos para la gestión de unidades frigoríficas, vitrinas y mostradores refrigerados. Os POEZ* s'apo-tenen amb relés estàndard. Os POEZV* s'han dissenyats específicament per a ús en aplicacions amb refrigerants infla-mables. Models disponibles:

C1: SPORLAN PRESSURE-TEMPERATURE CHART

TEMPERATURE - PRESSURE CHART
NATURAL REFRIGERANTS




At Sea Level, psig

www.sporlanonline.com

REFRIGERANT TYPE (SAFETY CLASS)				REFRIGERANT (SPORLAN LETTER CODE)				REFRIGERANT TYPE (SAFETY CLASS)				REFRIGERANT (SPORLAN LETTER CODE)				REFRIGERANT TYPE (SAFETY CLASS)				REFRIGERANT (SPORLAN LETTER CODE)			
TEMP.				TEMP.				TEMP.				TEMP.				TEMP.				TEMP.			
°F				°C				°F				°C				°F				°C			
HC (A3)				HC (A3)				HC (A3)				HC (A3)				HC (A3)				HC (A3)			
290(O)				441A				290(O)				441A				290(O)				441A			
170(K)				600a(U)				170(K)				600a(U)				170(K)				600a(U)			
AMMONIA (B2L)				717(A)				AMMONIA (B2L)				AMMONIA (B2L)				AMMONIA (B2L)				AMMONIA (B2L)			
ODZ (A1)				744				ODZ (A1)				ODZ (A1)				ODZ (A1)				ODZ (A1)			
-50	-45.6	78.9	4.3	21.1	23.6	14.3	103.4	-50	-45.6	78.9	4.3	21.1	23.6	14.3	103.4	-50	-45.6	78.9	4.3	21.1	23.6	14.3	103.4
-45	-42.8	88.1	0.9	19.7	22.6	11.7	116.6	-45	-42.8	88.1	0.9	19.7	22.6	11.7	116.6	-45	-42.8	88.1	0.9	19.7	22.6	11.7	116.6
-40	-40.0	98.1	1.4	18.1	21.4	8.8	131.0	-40	-40.0	98.1	1.4	18.1	21.4	8.8	131.0	-40	-40.0	98.1	1.4	18.1	21.4	8.8	131.0
-35	-37.2	108.7	3.4	16.3	20.2	5.4	146.5	-35	-37.2	108.7	3.4	16.3	20.2	5.4	146.5	-35	-37.2	108.7	3.4	16.3	20.2	5.4	146.5
-30	-34.4	120.0	5.7	14.3	18.8	1.6	163.1	-30	-34.4	120.0	5.7	14.3	18.8	1.6	163.1	-30	-34.4	120.0	5.7	14.3	18.8	1.6	163.1
-29	-33.9	122.4	6.1	13.8	18.5	0.8	166.6	-29	-33.9	122.4	6.1	13.8	18.5	0.8	166.6	-29	-33.9	122.4	6.1	13.8	18.5	0.8	166.6
-28	-33.3	124.7	6.6	13.4	18.1	0.0	170.1	-28	-33.3	124.7	6.6	13.4	18.1	0.0	170.1	-28	-33.3	124.7	6.6	13.4	18.1	0.0	170.1
-27	-32.8	127.1	7.1	12.9	17.8	0.4	173.7	-27	-32.8	127.1	7.1	12.9	17.8	0.4	173.7	-27	-32.8	127.1	7.1	12.9	17.8	0.4	173.7
-26	-32.2	129.6	7.6	12.5	17.5	0.8	177.3	-26	-32.2	129.6	7.6	12.5	17.5	0.8	177.3	-26	-32.2	129.6	7.6	12.5	17.5	0.8	177.3
-25	-31.7	132.1	8.1	12.0	17.2	1.3	181.0	-25	-31.7	132.1	8.1	12.0	17.2	1.3	181.0	-25	-31.7	132.1	8.1	12.0	17.2	1.3	181.0
-24	-31.1	134.6	8.6	11.5	16.8	1.7	184.8	-24	-31.1	134.6	8.6	11.5	16.8	1.7	184.8	-24	-31.1	134.6	8.6	11.5	16.8	1.7	184.8
-23	-30.6	137.1	9.1	11.0	16.5	2.2	188.5	-23	-30.6	137.1	9.1	11.0	16.5	2.2	188.5	-23	-30.6	137.1	9.1	11.0	16.5	2.2	188.5
-22	-30.0	139.7	9.6	10.5	16.2	2.6	192.4	-22	-30.0	139.7	9.6	10.5	16.2	2.6	192.4	-22	-30.0	139.7	9.6	10.5	16.2	2.6	192.4
-21	-29.4	142.3	10.2	10.0	15.8	3.1	196.3	-21	-29.4	142.3	10.2	10.0	15.8	3.1	196.3	-21	-29.4	142.3	10.2	10.0	15.8	3.1	196.3
-20	-28.9	144.9	10.7	9.5	15.4	3.6	200.2	-20	-28.9	144.9	10.7	9.5	15.4	3.6	200.2	-20	-28.9	144.9	10.7	9.5	15.4	3.6	200.2
-19	-28.3	147.6	11.3	9.0	15.1	4.1	204.2	-19	-28.3	147.6	11.3	9.0	15.1	4.1	204.2	-19	-28.3	147.6	11.3	9.0	15.1	4.1	204.2
-18	-27.8	150.3	11.8	8.4	14.7	4.6	208.3	-18	-27.8	150.3	11.8	8.4	14.7	4.6	208.3	-18	-27.8	150.3	11.8	8.4	14.7	4.6	208.3
-17	-27.2	153.0	12.4	7.9	14.3	5.1	212.4	-17	-27.2	153.0	12.4	7.9	14.3	5.1	212.4	-17	-27.2	153.0	12.4	7.9	14.3	5.1	212.4
-16	-26.7	155.7	13.0	7.3	13.9	5.6	216.5	-16	-26.7	155.7	13.0	7.3	13.9	5.6	216.5	-16	-26.7	155.7	13.0	7.3	13.9	5.6	216.5
-15	-26.1	158.5	13.6	6.7	13.5	6.2	220.8	-15	-26.1	158.5	13.6	6.7	13.5	6.2	220.8	-15	-26.1	158.5	13.6	6.7	13.5	6.2	220.8
-14	-25.6	161.4	14.2	6.1	13.1	6.7	225.0	-14	-25.6	161.4	14.2	6.1	13.1	6.7	225.0	-14	-25.6	161.4	14.2	6.1	13.1	6.7	225.0
-13	-25.0	164.2	14.8	5.5	12.7	7.3	229.4	-13	-25.0	164.2	14.8	5.5	12.7	7.3	229.4	-13	-25.0	164.2	14.8	5.5	12.7	7.3	229.4
-12	-24.4	167.1	15.4	4.9	12.2	7.8	233.8	-12	-24.4	167.1	15.4	4.9	12.2	7.8	233.8	-12	-24.4	167.1	15.4	4.9	12.2	7.8	233.8
-11	-23.9	170.0	16.1	4.3	11.8	8.4	238.2	-11	-23.9	170.0	16.1	4.3	11.8	8.4	238.2	-11	-23.9	170.0	16.1	4.3	11.8	8.4	238.2
-10	-23.3	173.0	16.7	3.7	11.4	9.0	242.7	-10	-23.3	173.0	16.7	3.7	11.4	9.0	242.7	-10	-23.3	173.0	16.7	3.7	11.4	9.0	242.7
-9	-22.8	176.0	17.4	3.0	10.9	9.6	247.3	-9	-22.8	176.0	17.4	3.0	10.9	9.6	247.3	-9	-22.8	176.0	17.4	3.0	10.9	9.6	247.3
-8	-22.2	179.0	18.0	2.4	10.4	10.3	251.9	-8	-22.2	179.0	18.0	2.4	10.4	10.3	251.9	-8	-22.2	179.0	18.0	2.4	10.4	10.3	251.9
-7	-21.7	182.1	18.7	1.7	10.0	10.9	256.6	-7	-21.7	182.1	18.7	1.7	10.0	10.9	256.6	-7	-21.7	182.1	18.7	1.7	10.0	10.9	256.6
-6	-21.1	185.2	19.4	1.0	9.5	11.5	261.3	-6	-21.1	185.2	19.4	1.0	9.5	11.5	261.3	-6	-21.1	185.2	19.4	1.0	9.5	11.5	261.3
-5	-20.6	188.3	20.1	0.3	9.0	12.2	266.1	-5	-20.6	188.3	20.1	0.3	9.0	12.2	266.1	-5	-20.6	188.3	20.1	0.3	9.0	12.2	266.1
-4	-20.0	191.5	20.8	0.2	8.5	12.9	271.0	-4	-20.0	191.5	20.8	0.2	8.5	12.9	271.0	-4	-20.0	191.5	20.8	0.2	8.5	12.9	271.0
-3	-19.4	194.7	21.5	0.6	8.0	13.6	275.9	-3	-19.4	194.7	21.5	0.6	8.0	13.6	275.9	-3	-19.4	194.7	21.5	0.6	8.0	13.6	275.9
-2	-18.9	197.9	22.2	0.9	7.5	14.3	280.9	-2	-18.9	197.9	22.2	0.9	7.5	14.3	280.9	-2	-18.9	197.9	22.2	0.9	7.5	14.3	280.9
-1	-18.3	201.2	22.9	1.3	7.0	15.0	285.9	-1	-18.3	201.2	22.9	1.3	7.0	15.0	285.9	-1	-18.3	201.2	22.9	1.3	7.0	15.0	285.9
0	-17.8	204.5	23.7	1.7	6.4	15.7	291.0	0	-17.8	204.5	23.7	1.7	6.4	15.7	291.0	0	-17.8	204.5	23.7	1.7	6.4	15.7	291.0
1	-17.2	207.9	24.5	2.1	5.9	16.4	296.2	1	-17.2	207.9	24.5	2.1	5.9	16.4	296.2	1	-17.2	207.9	24.5	2.1	5.9	16.4	296.2
2	-16.7	211.3	25.2	2.5	5.3	17.2	301.5	2	-16.7	211.3	25.2	2.5	5.3	17.2	301.5	2	-16.7	211.3	25.2	2.5	5.3	17.2	301.5
3	-16.1	214.7	26.0	2.9	4.8	18.0	306.8	3	-16.1	214.7	26.0	2.9	4.8	18.0	306.8	3	-16.1	214.7	26.0	2.9	4.8	18.0	306.8
4	-15.6	218.2	26.8	3.3	4.2	18.8	312.1	4	-15.6	218.2	26.8	3.3	4.2	18.8	312.1	4	-15.6	218.2	26.8	3.3	4.2	18.8	312.1
5	-15.0	221.7	27.6	3.7	3.6	19.6	317.6	5	-15.0	221.7	27.6	3.7	3.6	19.6	317.6	5	-15.0	221.7	27.6	3.7	3.6	19.6	317.6
6	-14.4	225.2	28.4	4.1	3.0	20.4	323.1	6	-14.4	225.2	28.4	4.1	3.0	20.4	323.1	6	-14.4	225.2	28.4	4.1	3.0	20.4	323.1
7	-13.9	228.8	29.2	4.5	2.4	21.2	328.6	7	-13.9	228.8	29.2	4.5	2.4	21.2	328.6	7	-13.9	228.8	29.2	4.5	2.4	21.2	328.6
8	-13.3	232.4	30.1	5.0	1.8	22.1	334.2	8	-13.3	232.4	30.1	5.0	1.8	22.1	334.2	8	-13.3	232.4	30.1	5.0	1.8	22.1	334.2
9	-12.8	236.0	30.9	5.4	1.2	22.9	339.9	9	-12.8	236.0	30.9	5.4	1.2	22.9	339.9	9	-12.8	236.0	30.9	5.4	1.2	22.9	339.9

To determine Subcooling for 400-Series blends, use Bubble Point in Gray.
To determine Superheat for 400-Series blends, use Dew Point in Blue.


Pressure, psig (pounds per square inch gauge), 80.0
Vacuum, inHg (inches of Mercury), 14.7



USE THIS QR CODE
TO DOWNLOAD
CHILLMASTER P-T APP




P-T data generated by INST Refrigerant



*Exceeds critical temperature



D1: PARTS LIST



A	Cornice
B	Case Top
C	Interior End Panel
D	Die Board Plex
E	Die Board
F	Condenser Air Intake
G	Front Toekick
H	Product Stop
I	Air Return
J	Insulated Drain Pan
K	End Panel Trim
L	End Panel
M	End Toekick
N	Outside Back
O	Bottom Deck
P	Adjustable Shelf Bracket
Q	Shelf Standard
R	Price Tag Molding
S	Inside Back
T	Air Discharge



Hill PHOENIX, Inc.
Hereinafter Referred To As Manufacturer

LIMITED WARRANTY

GENERAL WARRANTY

Manufacturer's products are warranted to be free from defects in materials and workmanship under normal use and maintenance for fourteen months from date of shipment from manufacturer (the "Base Warranty Period"). In the event of a qualifying warranty claim, a new or rebuilt part to replace any defective part will be provided without charge. The replacement part is covered under this warranty for the remainder of the applicable Base Warranty Period. In order to be eligible for warranty coverage, customer must: (i) notify Manufacturer promptly upon discovery of a warrant defect, and (ii) comply with the warranty claim procedures provided by Manufacturer from time to time.

This equipment warranty does not include labor or other costs incurred for diagnosing, repairing, removing, installing, shipping, servicing, or handling of either defective parts or replacement parts.

The warranty shall not apply:

1. To any unit or any part thereof which has been subject to accident, alteration, negligence, misuse or abuse, or which has not been operated in accordance with the manufacturer's recommendations, or in conditions outside of Manufacturer's specifications, or if the serial number of the unit has been altered, defaced, or removed.
2. When the unit, or any part thereof, is damaged by fire, flood, or other act of God.
3. To products that are impaired or damaged due to improper installation.
4. When installation and startup forms are not properly completed or returned within two weeks after startup.
5. If the defective part is not returned to the Manufacturer.
6. To service, maintenance or wear and tear parts (such as lights, starters and ballasts)

MODIFICATIONS TO GENERAL WARRANTY

The following sets forth certain modifications to the General Warranty for specific products of Manufacturer:

DISPLAY CASE AND SPECIALTY PRODUCTS CLEARVOYANT® LED LIGHTING

The warranty period for Clearvoyant LED lighting components within the Clearvoyant lighting system is five years from date of shipment.

REMEDY LIMITATION/DAMAGES EXCLUSION

THE REMEDY OF REPAIR OR PROVISION OF A REPLACEMENT PART WITHOUT CHARGE SHALL BE THE EXCLUSIVE REMEDY FOR ANY WARRANTY CLAIM HEREUNDER. WITHOUT LIMITING THE FOREGOING, MANUFACTURER SHALL NOT BE LIABLE UNDER ANY CIRCUMSTANCES FOR INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES, INCLUDING LOSS OF PROFIT, LABOR COST, LOSS OF REFRIGERANT OR FOOD PRODUCTS.

EXCLUSIVE WARRANTY

THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY WITH RESPECT TO THE PRODUCTS. ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED AND EXCLUDED. NO IMPLIED WARRANTY SHALL BE DEEMED CREATED BY COURSE OF DEALING OR USAGE OF TRADE. NO OTHER PERSON IS AUTHORIZED TO EXPAND OR CREATE ANY OBLIGATION GREATER THAN OR MORE EXPANSIVE THAN THE WARRANTY PROVIDED HEREIN.

Submit warranty claims to:

Hillphoenix Refrigeration & Power

Systems Division

2016 Gees Mill Road

Conyers, GA 30013

Warranty / Service

Phone: 1-833-280-5714

Hillphoenix Display Case Division

1925 Ruffin Mill Road

Colonial Heights, VA 23834

Warranty / Service

Phone: 1-833-280-5714

Hillphoenix Specialty Products Division

703 Franklin Street

Keosauqua, IA 52565

Warranty / Service

Phone: 1-833-280-5714

Warning

Maintenance & Case Care

When cleaning cases the following must be performed PRIOR to cleaning:

To avoid electrical shock, be sure all electric power is turned off before cleaning. In some installations, more than one switch may have to be turned off to completely de-energize the case.

Do not spray cleaning solution or water directly on fan motors or any electrical connections.

All lighting receptacles must be dried off prior to insertion and re-energizing the lighting circuit.

Please refer to the Use and Maintenance section of this installation manual.

Hillphoenix®

a **DOVER** company

Tel: 319-293-3777

703 Franklin Street, PO Box 478, Keosauqua, IA 52565

Due to our commitment to continuous improvement, all specifications are subject to change without notice.

Hillphoenix is a Sustaining Member of the American Society of Quality.

Visit our website at www.hillphoenix.com

